


<b>Panel</b>	Cutler Hammer CH Series 150 & 200 Vertical operated main at bottom of panel 2 ¼ spacing from top of main to bottom left breaker
<b>Model</b>	EAT-CH200U Pat. Pending
<b>Main Breaker</b>	150 or 200 amp single handle Vertical throw up (on) to down (off)
<b>Generator Breaker</b>	Left side 2 positions
	

## WARNING

**Only qualified personnel should be working on the panel box**  
**An amateur should *NEVER* open the panel box**  
**Please follow all rules and regulations of the National Electric Code**

Step 1: Place the drill plate (holes only) below the bottom left breaker and mark holes. Throw away drill plate after use, not used on this panel after marking holes.



Step 2: Turn off main breaker and remove panel cover.

Step 3: Drill holes as marked on panel cover with supplied 3/16 drill bit and remove all burs from drilling cover and dispose of this plate at this time.

Step 4: Insert screws from rear of cover, and install slotted top plate only, and install retaining nuts. Ensure proper movement.

Step 5: Install 2 pole Generator breaker on top left side and place Generator Warning Sticker on Generator breaker.

Step 6: Re-Install panel cover, Verify proper operation of interlock. Main breaker **ON**, generator breaker **OFF** and generator breaker **CAN NOT** be turned on. Generator breaker **ON**, main breaker **OFF** and main breaker **CAN NOT** be turned on.



Generator on



Main on

Step 8: Place Generator start-up procedure label on panel box, Place CAUTION label on panel box and electric meter pan.

The MAIN and the GENERATOR breakers should NEVER be able to be turned on at the same time. If panel cover is removed the Generator breaker is NEVER to be turned on. If for any reason the interlock does not function properly, DO NOT USE and contact us immediately at [sales@GenInterlock.com](mailto:sales@GenInterlock.com) for support and instructions.

Thank You for your support,  
GenInterlock Team

**DISCLAIMER:** GenInterlock.com is NOT responsible for misuse or improper installation. All electrical equipment should be installed and maintained by qualified personnel. Any consequences arising from improper use is the responsibility of the user.

GenInterlock.com  
2227 US Highway 1 – Unit 124  
North Brunswick, NJ 08902  
[Sales@geninterlock.com](mailto:Sales@geninterlock.com)  
732-339-4191