

Panel	Cutler Hammer BR Series 150 & 200
	Meter Main Single Row
Model	BRMM4
Main Breaker	150 or 200 amp single handle Horizontal throw left (on) to right (off)
	4 1/8 spacing between bottom of main breaker and breaker on the left
Generator Breaker	First 2 positions
WARNING	
Only qualified personnel should be working on the panel box	
An amateur should <u>NEVER</u> open the panel box Please follow all rules and regulations of the National Electric Code	

Step 1: Disassemble the interlock. Place the bottom plate (holes only) above the top left breaker and mark holes.




- Step 2: Turn off main breaker and remove panel cover.
- Step 3: Drill holes as marked on panel cover with supplied 3/16 drill bit and remove all burs from drilling cover.
- Step 4: Insert screws from rear of cover, install bottom plate, and install top plate (slotted) install thread lock to screws and install retaining nuts. Ensure proper movement.
- Step 5: Install 2 pole Generator breaker in first 2 positions and place Generator Warning Sticker on Generator breaker.
- Step 6: Install zip tie under metal plate and combine with 2nd tie then around top of breaker as shown in picture below. Pull on ends to make tight around breaker and trim ties as needed. Install warning label on zip ties next to breaker.



Step 7: Re-Install panel cover, Verify proper operation of interlock. Main breaker **ON**, generator breaker **OFF** and generator breaker **CAN NOT** be turned on. Generator breaker **ON**, main breaker **OFF** and main breaker **CAN NOT** be turned on.





The MAIN and the GENERATOR breakers should NEVER be able to be turned on at the same time. If panel cover is removed the Generator breaker is NEVER to be turned on. If for any reason the interlock does not function properly, DO NOT USE and contact us immediately at sales@GenInterlock.com for support and instructions.

Thank You for your support, GenInterlock Team

DISCLAIMER: GenInterlock.com is NOT responsible for misuse or improper installation. All electrical equipment should be installed and maintained by qualified personnel. Any consequences arising from improper use is the responsibility of the user.

GenInterlock.com Sales@geninterlock.com 732-339-4191